No.201-1

# basic audio

by NORMAN H. CROWHURST



## VOL. 1

THE NATURE OF SOUND
ACOUSTICS
MICROPHONES
LOUDSPEAKERS
BAFFLES & HORNS
OTHER TYPES OF SPEAKERS
IMPEDANCE MATCHING
DIVIDING NETWORKS & CROSSOVERS
RESONANCE

a RIDER publication

# basic audio

## by NORMAN H. CROWHURST

## VOL. 1

JOHN F. RIDER PUBLISHER, INC.
116 West 14th Street • New York 11, N. Y.

**Copyright August 1959 by John F. Rider Publisher, Inc.**

All rights reserved. This book or any parts thereof may not be reproduced in any form or in any language without permission of the publisher.

Library of Congress Catalog Card Number 58-13425

Printed in the United States of America

# PREFACE

Audio is like Topsy: it wasn't born, it just growed. Whatever Topsy may have been like, Audio has grown like a gawky child—not always in proportion! Originally associated with radio and later with high fidelity, audio now finds application in many other places—to name a few: computors, automation, ballistics and guidance for missiles, sonar detection for navigation, ultra- and infra-sonics for medicine, both diagnostic and therapeutic, as well as geophysical and other work. In fact Audio is now one of the largest and most basic divisions of electronics.

Courses in audio were nonexistent not too many years ago. Since then, textbooks and courses have appeared. But their approach follows the principle of many professors: "I learned it the hard way—you'll have to!" It's like learning watchmaking from a bridge-building man.

My wide experience in various aspects of audio has shown the need for a better way. In industry, in academic education, and particularly in working with graduates from college, this need is evident. My extensive technical writing for magazines and consultant work in the industry have also shown me audio's educational needs.

Many competent "practical men" find themselves hindered by lack of academic background in the subject. They can do their job in their own established "groove." But they do not have—and find it impossible to acquire—the background to enable them to expand outside this groove. These people need help in closing the gap between "theory" and "practice."

Engineers are conversant with the accepted "technical language," but they read the literature with only an "intuitive comprehension" (or should it be apprehension?). Their education dragged them past many "awkward spots" about which they have never felt really "comfortable." Like the King of Siam in "The King and I," they find many facts of which they wish they were more certain they are sure.

Very important are the new students, technicians, and audiophiles. They will need a basic education in audio to enable them to add their contribution to progress (and to earn themselves a living!). Why make it difficult? They'll do much better if they can get a good start.

All-in-all, it is time that certain roundabout approaches to this key subject were eliminated. We need a direct, meaningful way to take the place of the difficult detours. Then each of our three groups can not only "learn audio," but also understand it! This three-volume book results from the author's extensive education research. The finished arrangement achieves a completely new directness.

Let me give just one example: how many understand the behavior of a coupling capacitor, particularly its contribution to amplifier transient performance, and what sometimes happens to feedback? This has always been based on the concept of capacitive reactance, which does not adequately *explain* all the effects. We have adopted a practical "what happens?" approach.

As a result, someone who learned this the old way may miss the familiar landmark of the reactance concept—when he expects it; a closer examination will reveal the reason for postponing it: the whole presentation has been arranged to avoid the "dead spots" left by the traditional approach.

Inevitably such a change of approach will mean a change of stress. I make no apology for this. I know from practice that it is far more successful in getting Basic Audio "across."

It would be impossible to acknowledge the very many who have, knowingly or unknowingly, contributed to my experience, making this book possible. But I would like to express my thanks to the John F. Rider staff for their cooperation in "packaging" it in a form that interprets my intentions so well.

NORMAN H. CROWHURST

*New York, N.Y.*
*August 1959*

# CONTENTS

## VOL. I—BASIC AUDIO

Introduction 1
The Nature of Sound 2
Questions and Problems 25
Acoustics 26
Questions and Problems 46
Microphones 47
Questions and Problems 62
Loudspeakers 63
Baffles 68
Horns 72
Other Types of Speakers 82
Questions and Problems 86
Impedance Matching 87
Dividing Networks and Crossovers 93
Resonance 103
Audio Response Curves 106
Questions and Problems 111
Index 114

### What Audio Is

In the early days of radio, the word "audio" was used to describe the part of a radio receiver (or transmitter) that amplifies the audio, or sound frequencies. After detecting (later called *demodulating)* the radio waves or carrier, the signal was rather feeble, hardly sufficient to be audible in the headphones, so an *audio* amplifier was used to make the feeble signal audible in comfort. A similar amplifier was needed at the transmitter to magnify the feeble microphone currents for modulation of the radio carrier.


Audio once meant the "sound" end of a radio receiver.
"audio end"

From those early beginnings, audio amplifiers have found more and more uses, and have improved in performance. Quite early, audio amplification was applied to the making and reproducing of phonograph records, giving us the first "electrical" reproduction. Since then, the methods developed have been used for many things: all kinds of control mechanisms for industry; sonar-type detection devices; vibration measuring equipment for aircraft and other types of development or research; and many of the "brain cells" used in electronic computers, to name just a few.

## What Sound Is

Air can move in different ways. One way can be illustrated by an oscillating electric fan. It blows the air at a comparatively slow speed, but moves quite a quantity of it. The slowness with which the air is moving is apparent because the draft of air reaches you a little while after the fan has stopped blowing in your direction. Here a large quantity of air is moved at a speed of only a few feet per second (much slower than sound travels). The air movement is large, and there is hardly any compression.


Oscillating Fan
Fan sets air in motion
Fan Moves Large Quantity of Air Slowly


air reaches paper strips


AIR IS PILED UP
SHOCK WAVE
PRESSURE BUILDUP OCCURS AT SUPERSONIC SPEEDS

When a jet aircraft breaks through the sound barrier, however, it encounters different (and, at first, strange) kinds of air movement. The aircraft is now traveling faster than sound, and the air in front of it is no longer moving freely, but is "piled up" at high pressure on the front surfaces of the plane. As the aircraft goes through space, more air piles up in front of it, while some escapes at the side, producing the well-known "shock wave." The air in front of the plane hardly moves (relative to the aircraft), but is in a state of high compression—just the opposite condition from the air moved by the fan. However, the aircraft must move faster than sound (about 750 miles an hour) to cause this effect.

Both these forms of air movement do not "carry" very far: air movement from a fan soon gets "lost," and the pressure buildup in front of the aircraft in supersonic flight is not very deep—at most a few feet.

## Characteristics of Sound Waves


GENERATION OF A SOUND WAVE
Because this air moves outward,
this air gets compressed.
Because this air is compressed,
this air moves outward.

Sound waves combine these two forms of movement so as to cover great distances with only small air movements. Take the sound of a hand clap—when your hands come together, a small amount of air is forced out quite suddenly at the last instant.

The air pushed out by the hands clapping has a momentary movement *and* some pressure, although both are quite small compared to the movement produced by the fan or the pressure buildup of the supersonic jet. Two things now happen at the same time:

1. Because the pressure of the air close to the hands is momentarily greater than that further away, air moves outward.
2. Because the air close to the hands is moving outward, the air immediately beyond it also gets compressed.

The two actions combine to keep the pressure and movement wave traveling at a natural speed—the propagation velocity of sound in air. This is *not* to be confused with the speed at which individual air particles move due to the wave.


DISTANCE
TIME
maximum movement of each particle
THIS shows how each air particle moves back and forth...
These very small movements passed from one particle to the next propagate the sound
How a SOUND WAVE TRAVELS
DISTANCE
TIME
sound wave travels this far in a given time although the separate air particles only move back and forth

**Characteristics of Sound Waves (contd.)**

Note that, after the wave has passed, the air stops moving. A body of air does *not* move with the wave, but the energy in the wave is passed on from particle to particle, in much the same way that (in the illustration) the impact of one penny is transmitted along a line of pennies.


How sound travels
The impact passes from one air particle to the next.

The natural speed, or propagation velocity, of sound is controlled by two properties of the air through which it travels:

1. How much squeezing more of it into a given space will increase its pressure—its compressibility (known technically as elasticity). This feature takes control of the air piled up in front of the supersonic jet.
2. How much force is needed to get a given quantity of it moving, or to stop its motion—its *density* (or mass per unit volume). This feature is responsible for carrying the draft created by the fan.

The natural speed, or propagation velocity, of sound in air is roughly 1100 feet per second, or 750 miles per hour.


PROPAGATION VELOCITY
OF SOUND is dependent
on elasticity (or compressibility)
and density of the medium

## How Fast Sound Travels

The speed, or propagation velocity, of sound depends on the elasticity of air and on its density. Although we do not normally measure these properties, we can easily find the temperature and barometric pressure of the air, which affect both its density and elasticity. What we would like to know is: "How does the speed of sound change with atmospheric pressure and temperature?"

Experiments and advanced theory provide the following answers:

1. Change in barometric pressure alters the density of air (how much of it there is in a given space) and its compressibility (the more compressed it is, the more it resists further compression). Both change together and neutralize their effect on velocity of sound, so it is not appreciably dependent on barometric pressure.
2. Change in temperature also affects both the density and compressibility of air, but not so as to neutralize as pressure does. A useful formula says that the velocity of sound in air is approximately 1086 feet per second at 0° Centigrade (the freezing point of water), and rises 2 feet per second for each Centigrade degree rise in temperature.



At 20° C (normal room temperature), sound travels at $1086 + (2 \times 20) = 1126$ feet per second.

## How Fast Sound Travels (contd.)


Determining The Speed Of Sound
A
B
C
D
E

Sound also travels in almost any medium besides air, because everything (except a vacuum) possesses the two necessary properties, density and compressibility. (Even the most "incompressible" substances "give" a little.) For example, water is about 80 times more dense than air, but it also offers an even greater opposition to compression. Owing to its greater density, we should expect sound to travel more slowly in water than it does in air. Water, however, is less compressible, which tends to make sound travel faster. The combined effect makes the speed of sound in water about 4.7 times faster than in air. The following table gives the speed of sound in different substances measured at 0°C:

| | | | |
|---|---|---|---|
| Air | 1086 feet per second | Brick | 11,980 feet per second |
| Water | 4700 feet per second | Iron | 16,000 feet per second |
| Pinewood | 10,900 feet per second | Steel | 16,360 feet per second |

### Sources of Sound

Most sounds are more than a single "pulse" of sound, such as a hand-clap. For example, the reed of a harmonica or accordion vibrates at its resonant frequency and allows the air to be emitted in "bursts." Each burst of air pressure and movement is radiated in the same way as a single hand-clap.


HOW A REED EMITS SOUND

There are also other forms of vibration that produce sound: a vibrating piano string causes the sound board of the piano to vibrate. This moves the air in contact with it, producing alternate waves of compression and expansion *(rarefaction)*. All stringed instruments use the same principle; in the violin, the string vibrations are transmitted to the body of the instrument, which moves the air in contact with it. In addition, there are wind instruments in which a column of air inside a tube vibrates in a manner controlled by the internal dimensions of the instrument. The contact of the air column with outside air at one end of the column or through an opening allows sound to be radiated.

All these sounds are produced by a *periodic* vibration at regular intervals (definite *frequency*). Other sounds are not rhythmic, and do not give musical tones because they are due to vibrations that are not regular or periodic—clapping, rattling, and scraping sounds, and all kinds of noises, like those that come from a factory, street, or kitchen, or even voices, except when singing.


HOW A VIOLIN EMITS SOUND

### Frequency and Pitch


FREQUENCY IS MEASURED IN CYCLES PER SECOND
recording chart
1 sec
1 sec
1 sec
1
1 sec
1 sec
writing stylus
vibrating tuning fork
Number of cycles in 1 second = Frequency

The frequency of a sound is a measure of how many vibrations occur in a given time; it is usually measured in vibrations per second. When the sound vibrations are converted into electrical waves for amplification, the frequency is referred to as *cycles per second*, often called *cycles* for short.

In music, difference of frequency is recognized as a change in *pitch*. In a piano, for example, the long, heavy strings vibrate slowly (you can actually see the individual vibrations), whereas the short light ones vibrate very rapidly. The slow (low-frequency) vibrations are recognized musically as low in pitch; the rapid (high-frequency) vibrations are recognized musically as high pitched.

## The Frequency Range of a Piano


LONG HEAVY STRINGS
SHORT THIN STRINGS
27.5
29.1
30.9
32.7
34.65
36.7
38.9
41.2
43.6
46.2
49
52
55
58.2
61.8
65.4
69.3
73.4
77.8
82.4
87.2
92.4
98
104
110
116.4
123.6
130.8
138.6
146.8
155.6
164.8
174.4
184.8
196
208
220
232.8
247.2
261.6
277.2
293.6
311.2
329.6
348.8
369.6
392
416
440
465.6
494.4
523.2
554.4
587.2
622.4
659.2
697.6
739.2
784
832
880
931.2
988.8
1046.4
1108.8
1174.4
1244.8
1318.4
1393.2
1478.4
1568
1664
1760
1862.4
1977.6
2092.8
2217.6
2348.8
2489.6
2636.8
2786.4
2956.8
3136
3328
3520
3724.8
3955.2
4185.6
A
A
A
A
A
A
A
A

### Frequency and Pitch (contd.)

Every time frequency is *doubled,* pitch changes one *octave.* A two-octave rise in pitch quadruples the frequency; a three-octave rise in pitch multiplies it eight times. Any two adjacent notes on a piano keyboard have a constant ratio between their frequencies; since there are twelve notes per octave, this ratio is a number that, multiplied by itself twelve times, equals 2. The difference in frequency between two successive notes on the keyboard is not constant, but the *ratio* between their frequencies is constant; the frequency of the upper note is 1.059 times that of the lower one.

$$1.059\times1.059\times1.059\times1.059\times1.059\times1.059\times1.059\times1.059\times1.059\times1.059\times1.059\times1.059 = 2 \text{ (very nearly)}$$

In ordinary arithmetic, the difference between successive numbers is always the same—one. A system of numbers or quantities where successive items are separated by a *constant fraction,* rather than by the same amount, is called a *logarithmic system.* The relationship between frequency and pitch is logarithmic, as may be seen from the fact that to raise the pitch each octave, the frequency has to be *multiplied* by a power of two, and to raise the pitch by any desired musical interval, the frequency has to be *multiplied* by a figure corresponding to that pitch interval.

This can be shown visually by using "logarithmic" paper, where the pattern of lines is repeated for every numerical increase of ten times, and the distance covered by each change of ten times is the same. Similarly, each ratio of two is the same distance on the scale, as is any other ratio.



PLOTTING FREQUENCIES ON A LOGARITHMIC SCALE

### Frequency and Pitch (contd.)

Different kinds of sound, both musical and otherwise, are characterized by different ranges of frequencies:



### Intensity and Loudness

As well as having different frequencies, sounds also differ in loudness. This means that the vibrations we hear are of greater or smaller intensity. The horn of an ocean liner produces such an intense vibration that you can feel it as well as hear it. A piece of paper held near the source of such a sound will vibrate hard enough to numb your fingers.

Vibrations That Can Be Felt



Piece of Paper Picks Up Sound

The ticking of a watch, however, is of very low intensity. Unless the surroundings are fairly "quiet" you may be unable to hear it at all. Certainly you would never hear it near the horn of an ocean liner.

**Intensity and Loudness (contd.)**

Sound intensity is a measure of the *acoustical power* transmitted by the sound wave. Intensity is measured in terms of a certain section of the wave, specified as one square centimeter in scientific measurements. (There are 6.45 square centimeters in a square inch.)


INTENSITY IS SOUND ENERGY
carried in 1 square centimeter of the wave
WAVE TRAVELS
this way
Surface of Wave

Any kind of power can be measured in watts. This is true of sound-waves. One-tenth of one quadrillionth of a watt (.000,000,000,000,0001 watt) of sound power passing through an area of one square centimeter is not quite audible, using a vibration frequency of 1000 cycles per second. One-quadrillionth of a watt (.000,000,000,000,001 watt), however, is easily audible. A sound that is loud enough to be almost painful represents an intensity of less than one-thousandth of a watt per square centimeter.

**Intensity and Loudness (contd.)**



Every time that the intensity (or power) of a sound wave is *multiplied* by ten, it sounds louder by about the same amount. (It sounds as if a similar "quantity" of sound has been *added.)* A change in intensity of ten times does not represent as great a change in loudness as one might expect. In fact, a change in intensity of 26% is just barely detectible. The range between the intensity at which a 1000-cycle sound is first heard (the *threshold of hearing)* and a point at which an increase in power ceases to give the impression of further increase in loudness is a trillion times. Thus each multiplication of ten in intensity is equivalent to about one-twelfth of the range from audibility to saturation.

Intensity and Loudness (contd.)

## WHEN INTENSITY IS PLOTTED ON A LOG SCALE,



### Intensity and Loudness (contd.)

Loudness increases by equal amounts not with equal additions of sound intensity, but rather with equal multiplications of intensity. In this respect, therefore, our response to a change in intensity is similar to our response to a change in frequency—it is logarithmic. (Note the similarity of the graph of intensity and loudness to the graph of frequency and pitch; both are plotted on a logarithmic scale.) The fact that this logarithmic relationship exists is generalized in a principle known as Fechner's Law, which states that "For a sensation to increase in arithmetic proportion, the stimulus must increase in geometric progression." Fechner's Law may be applied to the other senses as well as to hearing.

The basis of the loudness scale is a multiplication factor of 10. This unit (called a *bel)* is inconveniently large, since there are only 12 bels in the entire useful range of audibility at 1000 cycles. For this reason, a smaller unit, the *decibel* (one-tenth of a bel) is more commonly used. (Thus the range of useful audibility at 1000 cycles is 120 decibels.) The decibel (abbreviated *db)* is also a convenient unit because it represents the 26% intensity change that is the smallest possible change an average person can hear in the range of loudness at which the ear is most sensitive to change. Over most of the range a 2-db change is difficult to detect, and at higher levels an even greater change is necessary.


This sounds louder
We respond to sound intensity logarithmically
but not TWICE as loud as this.

Because our response to sound intensity is logarithmic, our impression of loudness can be quite deceiving. If, for example, we are listening to the radio at low volume, we may not realize just how low the volume is, until an airplane passes over. The radio seems to become even less loud as the sound of the airplane drowns it out and our ears become less sensitive to the quieter sound. (This effect, known as *masking,* will be discussed in greater detail later.) Our instinctive reaction when this occurs is to turn up the volume control.

**Demonstration of Relative Loudness**


With an ordinary linear resistor...
50 ohms
linear variable resistor
0 ohms
100 ohms
slider
Large change in volume
small change in volume
loudness does not vary in proportion to rotation.

This fact of the logarithmic sensation of loudness can be very easily demonstrated with a simple test, using an amplifier with a separate volume control and a loudspeaker. (A volume control is a resistor with a sliding contact; if an audio program is fed through the resistor and only part of it is picked off by means of the slider, the volume can be changed by moving the slider.) If the volume control is an ordinary variable resistor (with the resistance uniformly distributed), the intensity will be proportional to the angle between the slider position and the "zero" position. Using this kind of resistor for a volume control, the loudness does not sound as if it varies in direct proportion at all. In the first few degrees of rotation there is a big change in loudness, but further rotation makes hardly any additional change.

**Demonstration of Relative Loudness (contd.)**

**Comparison of UNIFORM and LOGARITHMIC RESISTORS**


From preamplifier
to main amplifier
1 volt
.1 volt
.01 volt
0 volt
5 volts
uniform resistor
From preamplifier
to main amplifier
.01 volt
.1 volt
.001 volt
1 volt
5 volts
0 volt
special "log" resistor

For this reason, variable resistors intended for use as volume controls are made differently. The resistance is not uniformly distributed, but rather is proportional to the *logarithm* of the angle of rotation from the zero end. Thus 50° of movement of the slider allows the passage of one-thousandth of a volt of audio signal; 100° may produce one-hundredth of a volt; 150°, one-tenth of a volt; 200°, one volt, and so on. When this kind of control is used, the volume, or loudness, seems to be proportional to the amount of rotation of the control.

### Harmonics or Overtones

We have described the two main properties of any single sound: frequency (which we recognize as pitch) and intensity (which we recognize as loudness). But there are other differences by which we can tell one sound from another, even if both are of the same frequency and intensity (pitch and loudness). For example, a violin and a flute do not sound the same, even when they play the same note equally loudly. The difference in sound *quality* or *timbre* arises from the fact that every note on any musical instrument consists of not just one frequency, but a combination of several frequencies.

A STRING VIBRATING IN DIFFERENT WAYS PRODUCES DIFFERENT OVERTONES.


FUNDAMENTAL VIBRATION
SECOND HARMONIC (FIRST OVERTONE)
THIRD HARMONIC (SECOND OVERTONE)
FOURTH HARMONIC (THIRD OVERTONE)

These additional frequencies are multiples of the lowest frequency (called the *fundamental),* which is usually the one that determines the pitch of the note. If the fundamental is 440 cycles per second (A above middle C), the same instrument will produce a range of frequencies that are multiples of 440 cycles at the same time: 2 × 440, or 880 cycles, 3 × 440, or 1320 cycles, and so on up the scale. What makes the different instruments easily distinguishable is the fact that these *overtones* (or *harmonics)* may be present in different relative intensities; some may be absent entirely. Each instrument has its own characteristic "selection" of overtones in characteristic relative intensities.

### Harmonics in Strings

That it is differences in the overtone structure that account for the different "sound" of various instruments can be verified with an electric guitar. With this instrument, the strings themselves produce relatively little sound. An electrical pickup placed close to the strings is used to pick up their vibration, which is amplified electronically, the sound being heard from a loudspeaker. If you take one of these guitars and try moving the pickup to different parts of the string, you will find that the *timbre* of the note changes.

Assume that after the string has been set vibrating, the amplitude of vibration of the string is 1/10 inch at the lowest frequency, 1/20 inch at the next above this, which is twice the frequency (the second harmonic or first overtone), 1/30 inch at the third harmonic or second overtone, 1/40 inch at the fourth harmonic or third overtone, and so on. Now suppose that we move the pickup to positions 1/10, 1/5, 1/4, and 1/3 of the length of the string from one end. The differences in timbre will be clearly audible. From the drawings we can find the magnitude of vibration at each point along the string for the fundamental and each harmonic. These can be made into a table:

| *Tone* | *Maximum vibration in inches* | *Vibration at pickup points in inches* | | | |
|---|---|---|---|---|---|
| | | *one tenth* | *one fifth* | *one fourth* | *one third* |
| Fundamental | .100 | .031 | .059 | .071 | .087 |
| 2nd harmonic | .050 | .029 | .048 | .050 | .043 |
| 3rd harmonic | .033 | .027 | .032 | .024 | .000 |
| 4th harmonic | .025 | .024 | .015 | .000 | .022 |
| 5th harmonic | .020 | .020 | .000 | .014 | .017 |

EXTENT OF VIBRATION *at various pickup points* FOR THE FIRST FIVE HARMONICS



## Harmonics in Strings (contd.)

Of course there is less output from the positions nearer the end, but this can be compensated for by extra amplification, so the tonal quality, as judged by the ear, will depend on how much of each overtone there is, *compared to the fundamental.* Let us adjust the table to give this information, by expressing the strength of each harmonic as a percentage of fundamental. We do this by dividing each vibration figure by that for the fundamental at the same point, and multiplying by 100%. For example, when the fundamental vibrates 0.031 inch and the harmonic is 0.029 inch, the harmonic is (0.029 × 0.031) × 100% = 93.7%. The table, completed in this way, then looks like this:

| | | *Vibration percentages* | | | |
|---|---|---|---|---|---|
| | | *Harmonics* | | | |
| *Pickup point* | *Fundamental* | *2nd* | *3rd* | *4th* | *5th* |
| one tenth | 100 | 93.7 | 87.1 | 77.5 | 64.5 |
| one fifth | 100 | 81.4 | 54.3 | 25.4 | 0 |
| one fourth | 100 | 70.5 | 33.8 | 0 | 19.8 |
| one third | 100 | 50.0 | 0 | 25.0 | 20.0 |

Now notice the difference in composition: the first position, 1/10 from the end, gives a large proportion of all harmonics; even the fifth harmonic is more than half as strong as the fundamental. The second position, 1/5 from the end, eliminates fifth harmonic, and leaves the others in different strengths. Each position gives different proportions of harmonics. But the most important difference is that the further we go from the end, the weaker *all* the harmonics get, compared with the fundamental. At 1/10 from the end, all the harmonics have more than half the amplitude of the fundamental. At 1/3 from the end, only the second harmonic is even half as strong as the fundamental; the others are much weaker.



**Harmonics in Strings (contd.)**

From this we can see that the tone quality, or timbre, of a stringed instrument will vary considerably if we change the point along the string where the sound is picked off. In most stringed instruments, the sound is taken from the bridge, which transmits it to the body of the instrument. This means that the pickup point is fixed.


WHEN THE PICKUP POINT IS FIXED,
Plucking here gives a brighter sound than plucking here.
THE PLUCKING OR BOWING POINT AND THE
The same note played on these two strings has a different sound.
VIOLIN
CELLO
INSTRUMENT'S RESONANCES CONTROL TIMBRE

In this case, the precise point at which the string is plucked or bowed influences the harmonics or overtones of the string that are set in vibration together with the fundamental, thus changing the tone quality. In addition, the natural vibration properties of the body of the instrument (called resonances) influence the relative strength of the various frequency components as they are radiated into the air as sound. This accounts for the characteristic differences between different instruments using the same kind of strings.

We can extend the same general idea of overtones, and the way they are excited, to other kinds of instruments, using pipes, reeds, vibrating bars or rods, or other basic sound generators—even triangles, bells or drums. Variations in the complex pattern of harmonics give each instrument its own character.

### Harmonics in Organ Pipes

Variation in overtone structure makes different stops on an organ give different tonal qualities. In a pipe organ, the wide pipes produce tones in which the fundamental predominates. Their sounds are deep and smooth. The thinner pipes of the same length produce many more harmonics than the wider pipes, and give full-bodied sounds. Still thinner pipes suppress the fundamental and give a thin or reedy tone. In an electronic organ, the harmonics put in (or left out) are controlled electronically, giving a similar variety of "tone color."

The pattern of overtones produced by a pipe also depends on whether the far end of the pipe is open or closed. Acoustic vibration is set up in the air column by a sheet of air directed toward the upper lip of the pipe. When this air passes inside the lip, it starts to compress the air inside the pipe. This inside pressure soon forces the air out again. As a result, the blown air alternately goes inside and outside the pipe, with a considerable back and forth movement of air particles occurring at the pipe mouth.

The frequency of oscillation at the mouth is determined by the pipe. The pressure wave travels up the pipe at the speed of sound. When it gets to the far end, if the end is closed, the pressure increases because it cannot be passed on. The pressure wave is therefore reflected back toward the mouth of the pipe. When it reaches the mouth, the air directed against the lip is forced to go outside the pipe. Since this represents half of a complete cycle and the pressure wave has traveled twice the length of the pipe, it is clear that a closed organ pipe is one quarter-wavelength long for its lowest frequency.


*Tone Generation in a Closed Pipe*

**Harmonics in Organ Pipes (contd.)**

The air at the mouth of a closed pipe can move freely, whereas the air at the far end cannot move at all. Thus the lowest (fundamental) frequency of such pipes is determined by the length of a wave that travels up to the top, produces increased pressure, and travels back down the pipe to produce outward motion of air at the mouth.


Harmonics in a Closed Pipe
Maximum Pressure Variation Occurs At These Points
Maximum Air Movement Occurs At These Points
FUNDAMENTAL
THIRD HARMONIC
FIFTH HARMONIC
SEVENTH HARMONIC

Any wave whose length is such that the return journey gets it to the mouth when the blown air is moving in the opposite way to the initial pulse—where the pipe is ¼ wavelength long, ¾ wavelength long, 1¼ wavelengths long, and so on—will tend to be present in the pipe. These wavelengths correspond to the *odd* harmonics of the fundamental. The even harmonics (whose wavelengths are such that the pipe is 1½ wavelength long, 1 wavelength long, etc.) are absent. Notice that, at the mouth and for waves other than the fundamental, at half-wave distances along the pipe, the movement of air in the going wave adds to that in the return wave, to produce a point where air *movement* is a maximum. At the closed end, and for waves other than fundamental, at half-wave distances from the closed end, the air pressure in the going and returning waves adds, producing a point where air *pressure* fluctuation is a maximum.

### Harmonics in Organ Pipes (contd.)

If the far end of the pipe is open, the pressure will drop suddenly because the wave is no longer confined in the pipe. In this case, the pressure wave is reflected as a *rarefaction.* When the reflected wave reaches the mouth, the air blown against the lip is directed into the pipe again and thus completes a full cycle while the wave and its reflection have traveled twice the length of the pipe. Thus the fundamental frequency of an open pipe is such that the pipe is half a wavelength long. Any wave whose length is such that the length of the pipe is an exact multiple of a half-wavelength—1 wavelength, 1½ wavelengths, etc.—can be sustained in an open pipe. These wavelengths correspond to all the harmonics of the fundamental frequency, and an open pipe produces a complete harmonic series.

TONE GENERATION AND HARMONICS IN AN OPEN PIPE


Pressure Buildup at Center
Air at Lip Divides
1.
Release at End Starts Rarefaction
Air at Lip Pushed Out
2.
Rarefaction Buildup at Center
Air at lip Divides Again
3.
Air Intake Starts New Pressure Buildup
Air at Lip Sucked In
4.
Fundamental
Second Harmonic
Third Harmonic
Fourth Harmonic

Just as in the closed pipe, there will be points where the pressures add up, and points where movements add up. Because of this action inside pipes, the waves do not seem to move. At the points where pressure has a maximum fluctuation, as at the end of a closed pipe, the air does not move, but changes in pressure according to the sound wave. At the points where movement is a maximum, as at the open end of an open pipe, or the mouth of either, there is little pressure fluctuation and a maximum of movement. For this reason, waves of this kind are called *standing waves.*

## QUESTIONS AND PROBLEMS

1. What two kinds of air movement combine to produce sound waves? Illustrate with a wave started by bursting an inflated paper bag.
2. What two properties of air (or any other medium through which sound travels) control propagation velocity of sound waves?
3. How does the speed of sound change with (a) barometric pressure, (b) atmospheric temperature? State any approximate rule that can be used.
4. State why you think sound waves travel faster in steel than in iron or brick.
5. What part of (a) a piano, (b) a violin, is responsible for radiating sound waves into the air?
6. Explain the relationship (a) between frequency and pitch, (b) between intensity and loudness. What frequency interval corresponds with a pitch interval of one semitone in music?
7. What is the ratio between intensities corresponding to (a) the full range of average human hearing, (b) the smallest change in loudness that can be detected with very careful listening?
8. How would Question 7 be answered in decibel units?
9. How does Fechner's Law explain the usefulness of the decibel scale?
10. Why do potentiometers for use as volume controls have a logarithmic gradation?
11. What are the three basic properties of a musical tone? On what properties of sound does each of these properties depend?
12. Why can a string vibrate at more than one natural frequency? Explain the relationship between the different frequencies at which it can vibrate.
13. Why do you think strings for the lowest notes on the piano are "loaded" by having a spiral of wire wound on over the central stretched one?
14. Suggest why the same violin, played by an accomplished musician, gives a much sweeter tone than when played by a novice.
15. What is the basic difference in the overtone structure of organ pipes with the "far" end open or closed?
16. If the same pipe is provided with a removable end plug, how will its pitch change from open to closed?
17. Why is it that a narrow organ pipe sounds thin or reedy, while a wide pipe gives a deep, smooth tone?
18. What are standing waves? Explain how they build up inside (a) a closed and (b) an open organ pipe.

## What Rooms Do To Sound

Most of the sounds that we are concerned with in audio exist in rooms. But to understand what happens to sound in rooms, remember that echo that can be heard in the mountains. Every sound made comes back a few seconds later, like a perfect mimic. A wall-like face of rock reflects the sound waves that are generated, and sends them back one or more times.



Because of the large open spaces in mountain areas and the time it takes sound to travel (about 4¾ seconds for each mile of travel), the reflected sound is heard so long after the original sound that it sounds quite separate from it. However, all surfaces reflect sound in the same way, even the walls in your living room. The difference is that the sound does not take so long in going to the reflecting surface and coming back, so the reflected sound does not get completely separated from the original sound.

You must have noticed at some time the difference in a room when all the furniture and rugs are removed (before moving into a new apartment or in preparation for the painters). Without the furniture and carpeting, the room sounds "hollow." When the furniture is in it, the room becomes pleasant to talk in. The hollow effect is due to the echo in the room from the wall surfaces. When the room is empty, the echo goes on bouncing from wall to wall a great many times; when the furniture is in, the echo is deadened.

## Why Sound Waves Reflect


Speed of Sound is Determined by Density and Elasticity of Medium
MOVEMENT IN BRICK WALL
AIR PARTICLE MOVEMENT DUE TO SOUND WAVE
SOUND WAVE APPROACHING
BRICK WALL
Pressure changes greatly but particles barely move

Sound will travel through anything except a vacuum, but the speed at which it travels is set by the density and elasticity of the material through which it is traveling. When sound, traveling in air, comes to the end of the air, it will start to penetrate whatever it strikes. The wave consists of both pressure and movement of the particles of the material through which it goes. The power in the given area of a sound wave is found by multiplying the pressure by the velocity, or rate of particle movement. Transmission in air uses a combination of large movement with small pressure, compared to transmission in, say, a brick wall.

Since the brick wall is much heavier, or denser, than air, the sound wave will not move the brick as much as it does the air. The pressure transmitted to the bricks will be the same as that built up in the air where it strikes them, but because the movement in the brick is very small, something different happens in the air where it touches the wall—it does not follow the same pressure and movement combination as air elsewhere, because the air hardly moves at all. This means that the pressure of the sound wave is almost doubled at this point. This "surplus" pressure starts another sound wave, directed away from the wall.

If the original wave strikes the wall at an angle, instead of "head on," the increase in pressure will follow the wave along the wall, as different parts of the original wavefront reach the wall. This results in the wave leaving the wall, just the same way that light gets reflected from a mirror.


Balls indicate Action of Reflecting Sound Wave
Increase in pressure follows wave along wall
BRICK WALL
C
B
A
C
B
A

### The Ripple Tank

Waves of water in a tank are reflected in the same way. You can watch this at high tide, where the incoming waves of the ocean strike a breakwater at an angle. This gives a kind of slow-motion picture of what happens to sound waves.

Acoustic architects use ripple tanks for examination of the effects of various shapes in building structure on the way waves get reflected round an auditorium. It proves a useful way of working out a good shape for a building without having to make a full-scale model and then try all over again if the acoustics are improper.

Use of THE RIPPLE TANK


Ripple started by disturbance here...
Continuous low-frequency vibration applied here

When a tone or sound is continued, reflection effects build up. A single clap, or other pulse of sound, is reflected in a sequence that can easily be traced in a ripple tank. To some extent, we can consciously discriminate between direct and reflected sounds in normal listening. But a continuous tone causes a sound *pattern* to be set up, called a *standing wave pattern.* This is similar to the standing wave set up inside an organ pipe, except that the one in the organ pipe is deliberately controlled and has a pattern in only one direction—along the pipe. Patterns in rooms or buildings are not so organized, and "stand" in several (at least two as a rule) directions across the room.

### Absorption


Absorbed Wave
Wall
Reflected Wave
Striking Wave

*When a sound wave changes medium, some of it is Reflected; and some of it is Absorbed*

Sound is never completely reflected. Some of it is also absorbed. If a sound wave hits the wall of a room, most of it will be reflected back into the room. Some of it, however, will go on into the wall. Some of it may even go out into the next room. This is the way sounds in one room can be heard in the next—through the wall.

Each time a wave encounters a change in medium, this happens. Some of it goes into the next medium; some of it gets reflected. The proportions depend on the differences between the two media (in the example, the air of the room and the substance of the wall), the wavelength of the sound waves, and the angle at which they strike.

If a sound wave is traveling parallel to a wall, the wavelength along the wall will be the same as in the wave traveling in air. Very little absorption will occur because the wavelength of the same frequency in the wall is much longer (since sound travels faster in the material of the wall).

If the wave hits the wall "head on," the reflection and absorption will divide according to the density and elasticity of the wall material compared to air. But if the wave hits at a particular angle, the wavelength along the wall due to the striking wave may be the same as the natural wavelength for this wave in the wall.

Because this tends to make the wall take up more of the sound wave, there is a critical angle at which a sound wave will strike a surface, at which it will absorb much more than either a head-on strike or traveling parallel.

*Possible ways for sound wave to strike wall*


Wall
Wave Parallel to Wall
NO ABSORPTION
Wall
Wave Strikes Wall Head-On
Wavelength in Wall
Shading Represents Progressive Absorption
Absorption in Wall
Wavelength in Air

### Standing Waves

As a result of this standing wave pattern, the normally definite sense of direction that enables us to tell where sounds come from is lost. This can be verified with an oscillator, amplifier, and loudspeaker, or by just getting an instrumentalist to play a single long note. The sound seems to fill the room. If you have an impression that the sound comes from one direction (with your eyes shut) you are probably wrong, and if you move your head slightly, it will seem to come from a different place.



*The Effect of Standing Waves*

**Cancellation occurs along the lines.**

**The + and − signs represent points of maximum intensity.**

**(When there is pressure at the points marked +, there is rarefaction at the points marked −.)**

**The arrows indicate the direction from which sound seems to come; the circle shows a position at which all sense of direction is lost.**

If your head is placed where a maximum intensity occurs by your right ear, and the left ear is at a point of less intensity, the sound will seem to come from your right side. If both ears are on a line of maximum intensity, or are at equal intensity, the sound will seem to be in front of you. And if both ears receive pressure at the same intensity, but one receives a pressure wave when the other receives a rarefaction wave, and vice versa, the impression of direction is confused.

**Standing Waves (contd.)**

Standing wave patterns take time to build up and, what is more important in acoustics, also take time to die away *(decay)*. When the vibration causing the standing waves in the water ceases, or when the tone in the room stops, the vibrations all over the area die out gradually, rather in the way that a swinging pendulum comes to rest when nothing continues to drive it.


When Sound Source is Removed
Standing Waves Die Out Gradually
AUDITORIUM
Music
Stops
AUDITORIUM
AUDITORIUM

This dying away occurs in a fraction of a second in an ordinary living room. Most of us are so used to the brief presence of these patterns that we do not normally notice it. In a large hall or auditorium, however, or in a stadium with walls all around it, the time required for sound to die away can be quite noticeable.

The time required for sound to die away after the originating tone ceases is called the *reverberation time* of the room or building. (Reverberation is the name given to "echo" when it is not sufficiently separated from the original sound to be noticed as a separate repetition.)

### The Inverse-Square Law


Expansion of a Sound Wave
SOUND SOURCE
1 sq. cm of wave
at double, the distance becomes 4 sq cm
at 3 times, the distance becomes 9 sq cm
at 4 times, the distance becomes 16 sq cm

In the absence of any reverberation, the sound goes on outwards in an ever-expanding wave. The farther the wave goes from its starting point the larger its area becomes. The energy in the wave does not increase, because the wave can only pass on the original amount of energy put into it. This means the intensity in a *square centimeter* of the wave (which is how intensity is measured) must decrease as we go farther from the source. It is like spreading a fixed amount of butter on two slices of bread. If one slice is larger than the other, the butter on it will be thinner.

Doubling the distance means the area is quadrupled, so the intensity must be divided by four. Multiplying the distance by any number means that the area is increased by the square of that number, which, in turn, means that the intensity must be divided by the square of the number. This fact is known as the *inverse-square law*.


The Inverse Square Law
$I \propto \frac{1}{d^2}$
Intensity of sound wave
Varies ...
Inversely as the square of the distance from sound source

### The Inverse-Square Law (contd.)



*Concentrating Sound into narrower angle permits sound to carry further*

The inverse-square law gives one reason why sound does not carry very far in the open air, unless there is something to make an echo. Cupping your hands or using a megaphone concentrates more of the original sound within a narrower angle, so that the power does not get scattered quite so widely. For this reason, the sound carries further in a particular direction. Because of reflection and reverberation effects, sound does not get "lost" so readily indoors.

## Masking

Although there is a big power difference from the quietest audible sound to the loudest that the ear can negotiate—about 1,000,000,000,000 times—we cannot listen effectively to both a very soft and a very loud sound at the same time. If sound A is too much louder than sound B, A drowns B out. The scientific name for this effect is *masking*.


Loud Sounds can 'drown out' or MASK Weaker Sounds
Audience Cannot Hear Speaker.
PNEUMATIC DRILL

While it is sometimes a matter of getting the sound we *want* to hear loud enough to be audible against a noisy background, at other times—when we want to listen to a high fidelity reproducer, for instance—our object is to get the sound loud enough so that we do *not* hear other, *unwanted* sounds. Or, more specifically, we wish to get the unwanted sounds so quiet that they cannot be heard while we listen to the music.

### Outdoor Acoustics

Have you ever wondered why sound travels much better "downwind" than against the wind? With sound traveling at about 750 miles an hour, a wind of only a few miles an hour will obviously not be able to *stop* the sound, although the speed of sound relative to the ground does vary with the wind speed.


HOW THE WIND BENDS
A Train of Sound Waves
WIND SPEED INCREASES ABOVE GROUND
55 mph
50
45
40
35
30
25
20
15
10
5
Sound Wave Travel
DIRECTION OF WIND
GROUND
55 mph
50
45
40
35
30
25
20
15
10
5
Sound Wave Travel
DIRECTION OF WIND
GROUND

The wind travels at different speeds at various heights above ground. Air in contact with the ground hardly moves at all, but the higher you go, the stronger the wind. For this reason, the higher part of the sound wave traveling *with* the wind moves faster than the part near the ground. (The wind speed is added to the normal speed of sound.) This makes the wave lean forward, and bear down on the ground, and the sound heard here is more intense than without the wind.

Traveling *against* the wind, sound at higher levels moves a little slower than on the ground, the wave leans back. It therefore "takes off" and does not carry to a listener on the ground.

## Listening Acoustics

It might be thought that to enjoy listening best, we should go outdoors where there is no reverberation. But in most outdoor locations, there is so much other noise going on, and the sound we want to listen to gets lost so quickly in all directions that we will not be satisfied. However, some quiet country locations are ideal for listening to music, which accounts for the increase in popularity of summer outdoor music festivals.

Quiet Country Locations are ideal for Music Listening



Using a room to listen in, whether it be our living room or an auditorium, helps to keep in the sound we want to hear, and to keep out what we don't want to hear. Reverberation helps to build up the intensity of the sound we want to hear, but there is a limit to the useful amount of reverberation. If we have too much, the sound seems to go on and on and on. Each new sound is blurred by the reverberation of the sounds that preceded it.

This phenomenon is closely linked with masking: reverberation should build up the sound, but not so much that it masks the original sound or succeeding ones. Every size of room or auditorium has an optimum amount of reverberation and length of reverberation time for music or speech that will give the most enjoyment from listening.

### Sound Composition

Every sound has its own individual composition: different frequencies at varying intensities, and recurring at intervals. Musical instruments have a definite pitch range, from the lowest note to the highest note that each of them can play. Above each note there is a range of overtones which must also be heard if we are to distinguish one instrument from others playing the same note.


Fidelity is the degree of faithfulness with which sound is reproduced
Clarinet
Drums
Horn
Sax
Piano
RECORD
INPUT
LOW-FIDELITY
JUKE BOX
PLAYBACK
OUTPUT
Washboard
Toy Trumpet
Bass Drum
Whistle

The faithfulness with which the sound reproduced through a loudspeaker copies the original is called the *fidelity* of the system. If all the original frequencies are present in their original proportions, the system has "high fidelity." In the average juke box—especially the older ones—the fidelity is very low. The tune, of course, can be recognized, but you would have difficulty in recognizing some of the instruments playing it.

### Directional Effects

Hearing all sounds in correct proportion is not only a matter of making sure that they come out of the loudspeaker that way. Different frequencies do not travel in rooms in quite the same way, so we may notice some peculiar effects because all the frequencies do not reach us properly.


A Good Loudspeaker produces a uniform sound wave
BUT
high freq
low freq
A Real Trumpet produces sound like this
SO
the Reproduced Sound is not like the real trumpet

For example, a trumpet gives out sound that is very rich in overtones. The lower (fundamental) notes of the trumpet go out in all directions, whereas the high-frequency sound is almost squirted in the direction in which the trumpet is pointed. This kind of sound production and the way in which the sound bounces around before reaching our ears have become part of our experience in listening to trumpets.

If a loudspeaker radiates all the correct frequencies to make up a trumpet sound, but distributes the high frequencies in all directions (in the same way as it does the lower frequencies), reproduction of the trumpet will not be realistic.

### Frequency and Wavelength

All sounds travel at the same speed, regardless of frequency. Because the waves are traveling, the length of a wave (measured along the direction it travels) from the peak of one wave to the peak of the next will be different, according to the frequency.


WAVELENGTH AND FREQUENCY
Waves travel this distance in one second.
Number of waves in this distance is frequency
1 Wavelength
$\lambda = \frac{c}{f}$
wavelength
propagation velocity
frequency

Sound moves at about 1100 feet per second. If the frequency of a sound is 440 cycles per second (A above middle C), there must be 440 cycles in a 1100-foot piece of the sound wave. Each wave is thus about 2½ feet long in this case. If the frequency is 8800 cycles (an octave beyond the end of a piano keyboard) the same space (1100 feet) will be occupied by 8800 cycles, or waves, and each must be only one eighth of a foot (about 1½ inches) long. Low frequencies from organ pipes may be down in the region of 32 cycles, with a wavelength of 34 feet.

## Long and Short Sound Waves


Many Rooms do not permit a complete Cycle of a Low Frequency
LOW FREQUENCY
LOW-PRESSURE AREA
HIGH-PRESSURE AREA
HIGH FREQUENCY
MANY WAVELENGTHS

As a result of the tremendous differences in wavelength, the low frequencies may not even have one complete wave in an average-sized room at the same instant, whereas a high-frequency sound will have many complete waves in the room traveling in a number of directions at the same time.

Because of its size, a low-frequency wave can hardly be recognized as such in a comparatively small room—it is more like a fluctuating pressure throughout the whole room at the same time. For this reason, it will fill the room, regardless of the room's shape. The higher frequencies, however, since they are smaller than most objects, such as walls and furniture, will be reflected whenever they strike a surface. For this reason, you may miss some of the high frequencies, not because they are not present, but because you happen to be sitting in a *shadow* zone.


HIGH FREQUENCIES can produce a SHADOW ZONE
High frequencies are reflected
and the obstacle causes a shadow
Low frequencies flow around objects

## Transients

The word "transient" means something that is passing or changing. Within the strict meaning of the word, any change, from silence to sound, for example, or from sound back to silence, would be classified as a transient, while the steady, unchanging tone is not a transient.


TRANSIENTS are IMPACT SOUNDS
audience
and get Attention more effectively than do Steady Tones

In audio, for two reasons, the word is used with a somewhat more restricted meaning. The first is connected with everyday listening experience, the second with the performance of audio equipment—microphones, amplifiers, loudspeakers, etc.

The start of any sound, whether sudden or gradual, will reach a listener before the reinforcement of the same sound by reverberation. When the sound finishes, the reverberation goes on. Because this happens all the time around us, our hearing faculty has formed the subconscious habit of paying more critical attention to the beginning of sounds than to the endings.

If the sound builds up relatively slowly, as in the deep notes of a pipe organ, the reverberation builds up almost as rapidly as the direct sound from the pipe. On the other hand, a sound that starts suddenly, like a hand clap, a drum beat, or any sound that has what we may call "impact," reaches the listener well ahead of its reverberation, and gives him a good chance to tell where it came from. Thus musical sounds that have impact, like a hand clap, can be regarded as attention-getting sounds.

## QUESTIONS AND PROBLEMS

1. What are the natural limitations to obtaining a voice coil of specific resistance? If a voice coil, wound in 4 layers, has a resistance of 10 ohms, what would be the approximate resistance of a coil of the same dimensions, wound of a wire whose gage would permit 5 layers?

2. What is matching (a) as applied to microphones, (b) as applied to loudspeakers? If a loudspeaker has a voice-coil resistance of 8 ohms and an amplifier output needs a load of 5000 ohms, what transformer turns ratio is needed?

3. If the voice-coil resistance in Question 2 were 10 ohms instead of 8 ohms, what load would be provided for the amplifier by the same transformer?

4. What led to the use of multiple loudspeaker units to cover the audio range?

5. Why are dividing networks used with multiple loudspeaker systems? What might result from failure to use a suitable network?

6. Networks consisting of resistance and capacitance or resistance and inductance produce division of voltage or current according to frequency. Why cannot networks of these types be used to feed power to loudspeakers?

7. What is basic difference between networks in which the elements are (a) in series, (b) in parallel?

8. In the simplest type crossover, suppose the crossover frequency is 800 cycles. How much of the total amplifier power of 10 watts goes to each unit, when the frequency is (a) 400 cycles, (b) 800 cycles, (c) 1600 cycles?

9. What is the effect of using more inductors and capacitors in crossover networks? Explain how this difference in response is achieved.

10. What is meant by phasing? How would you tell if two loudspeaker units were connected to provide correct phasing?

11. What is resonance? State in which of the following it is a desirable feature, and in which it is undesirable: piano, microphone, violin, marimba, loudspeaker, organ pipe, flute, oboe, phonograph pickup.

12. A moving-iron loudspeaker, when compared with a moving-coil type, actually seemed louder, although its quality was poor, particularly in the bass. Explain this with reference to the effect of resonance.

13. Explain how a simple device can be used to obtain calibration of the particle velocity of air in sound wave. Does a Rayleigh disk discriminate between waves from the back or front? Is it uniformly sensitive to sound waves from all directions?

14. Is human hearing uniformly sensitive to all audible frequencies, and does its sensitivity to different frequencies depend on their intensity?

# INDEX TO VOL. 1

Absolute standard, 1-105
Absorption, 1-29
Accordion, sound of, 1-7
Acoustic:
  amplifiers, 1-44
  lens, 1-81
  power, 1-12, 60
  slit, 1-80
Air, barometric pressure of, 1-5
  compression of, 1-2, 70
  density of, 1-5
  elasticity of, 1-5
  expansion in, 1-7
  modulated pressure in, 1-45
  movement, 1-2, 23, 50, 67 73, 106
  rarefaction in, 1-7, 24
  sound in, 1-6
  temperature of, 1-5
Amplifier, acoustic, 1-44
  electric, 1-45
  electronic, 1-45
  pneumatic, 1-45
Amplifier, calibrated, 1-109
Amplitude of vibration, 1-19
Anechoic room, 1-43
Audibility, range of, 1-13
Audio measurements, 1-106

Background, 1-43
Baffle, bass reflex, 1-70
  infinite, 1-69
  loudspeaker, 1-68
  phase in, 1-71
Barometric pressure of air, 1-5
Bass-reflex baffle, 1-70
Bells, sound from, 1-21
Bidirectional microphone, 1-56
Brick, sound in, 1-6
Build-up of sound, 1-28

Calibration of microphones, 1-107
Capacitor (in crossovers), 1-94 – 100
Carbon microphone, 1-55
Cardioid microphone, 1-57
Centering spider, 1-49
Closed pipe, 1-22
Coil (*see* Inductor and Voice coil)
Compressibility of air, 1-5
Compression of air, 1-2, 70
Computers, 1-1
Condenser microphone, 1-51
Cone, loudspeaker, 1-65
Crossover, parallel-fed, 1-97
  series-fed, 1-98
  three-element, 1-101
  two-element, 1-99
Crystal loudspeaker, 1-84
Crystal microphone, 1-53
Current-dividing network, 1-96
Cutter, phonograph, 1-105

Decay of sound, 1-31
Decibel, 1-15
Density of air, 1-5
Diaphragm, loading of, 1-69
  loudspeaker, 1-65, 83
  microphone, 1-47, 51, 54, 55
Directivity, horn, 1-79
  microphone, 1-56
Dividing networks, 1-96
  current, 1-93
  voltage, 1-94
Drums, sound of, 1-21, 104
Dynamic microphone, 1-48

Ear, response curves of, 1-110
  trumpet, 1-44
Echo, 1-26
Efficiency, loudspeaker, 1-72
Elasticity of air, 1-5
Electrical pickup, 1-19
Electronic amplifier, 1-45
Electrostatic loudspeaker, 1-82
  microphone, 1-51
Enclosures, loudspeaker, 1-68 – 79
Expansion of air, 1-7
  of wave, 1-32, 74
Exponential horn, 1-75

Fechner's Law, 1-15
Folded horn, 1-77
Frequency, 1-8
  fundamental, 1-18
  harmonic, 1-18
  logarithmic scale, 1-9
  low and high, 1-40
  instruments, 1-37
  range of musical
  wavelength and, 1-39, 66
Fundamental frequency, 1-18

Gradient, pressure, 1-50, 56
Guitar, sound of, 1-19

Harmonica, sound of, 1-7
Harmonics, 1-18
Headphones, 1-1
Hearing, threshold of, 1-13
High fidelity, 1-34
High-frequency radiation, 1-40
Horn:
  directivity, 1-79
  exponential, 1-75
  folded, 1-77
  loudspeaker, 1-72
  mouth size, 1-75
  re-entrant, 1-78
  shapes, 1-74
  throat, 1-74
  tractrix, 1-79

Impact, 1-4, 42
Impedance,
  microphone, 1-61
Impedance ratio, 1-92
Inductor (in crossovers), 1-95 – 100
Infinite baffle, 1-69
Intensity, 1-11
Intercommunication sets, 1-59
Inverse-square law, 1-32
Ionophone, 1-85
Iron, sound in, 1-6

Lens, acoustic, 1-81
Level difference, minimum perceptible, 1-15
Loading, diaphragm, 1-69
Logarithmic:
  frequency scale, 1-9
  loudness scale, 1-15
  volume control, 1-17
Loudness, 1-11
  scale of, 1-15
Loudspeaker:
  baffle, 1-68 – 79
  cone, 1-65
  crossovers, 1-93
  crystal, 1-84
  diaphragm, 1-65, 1-83
  efficiency, 1-72
  electrostatic, 1-82

  - enclosure, 1-68 – 79
  - folded-horn, 1-77
  - horn, 1-72 – 79
  - infinite, 1-69
  - matching, 1-88
  - moving-coil, 1-65
  - moving-iron, 1-64
  - need for, 1-63
  - phasing, 1-71, 102
  - radiation, 1-38
  - response curves, 1-108
- Low-frequency radiation, 1-40
- Magnetic structure, 1-48, 64, 65
- Marimba, sound of, 1-103
- Masking, 1-15, 34
- Matching, loudspeaker, 1-88
  - microphone, 1-60
  - need for, 1-87
  - transformer, 1-60, 89
- Measurements, audio, 1-105
  - vibration, 1-1
- Megaphone, 1-33, 44, 71
- Microphone, bidirectional, 1-56
  - calibrating, 1-107
  - carbon, 1-55
  - cardioid, 1-57
  - condenser, 1-51
  - crystal, 1-53
  - diaphragm, 1-47, 51, 54, 55
  - directivity, 1-56
  - dynamic, 1-48
  - electrostatic, 1-51
  - matching, 1-60
  - moving-coil, 1-48
  - need for, 1-47
  - omnidirectional, 1-56
  - piezoelectric, 1-53
  - pressure, 1-56
  - pressure-gradient, 1-50, 56
  - response curve, 1-108
  - ribbon, 1-50, 56, 60
  - sensitivity, 1-58
  - unidirectional, 1-57
  - velocity, 1-50
- Modulated air pressure, 1-45
- Movement of air, 1-2, 23, 50, 67, 73, 106
- Moving-coil loudspeaker, 1-65
- Moving-coil microphone, 1-48
- Moving-iron loudspeaker, 1-64
- Musical instruments, frequency range of, 1-37
- Noise, 1-7, 36
- Octave, 1-9
- Omnidirectional microphone, 1-56
- Open pipe, 1-24
- Organ, sound of, 1-21, 39
- Overtones, 1-18
- Parallel-fed networks, 1-96, 97
- Particle velocity, 1-3, 23, 58, 70
- Perceptible level difference, 1-15
- Periodic vibrations, 1-7
- Phase, 1-71, 102
- Phonograph, 1-1
  - cutter, 1-105
  - pickup, 1-103
- Piano, sound of, 1-7
- Pickup, electrical, 1-19
  - microphone, 1-56
  - phonograph, 1-103
- Piezoelectric loudspeaker, 1-84
  - microphone, 1-53
- Pipe, closed, 1-22
  - open, 1-24
- Pipes, sound of, 1-21, 103
- Pitch, 2-8
- Pneumatic amplifier, 1-45
- Polarizing carbon microphone, 1-55
  - condenser microphone, 1-52
- Port, 1-71
- Power, acoustical, 1-12, 60
  - from microphones, 1-60
  - to loudspeakers, 1-89
- Pressure, barometric, 1-5
  - microphone, 1-50, 56
  - sound, 1-23, 58, 70
- Pressure-gradient microphone, 1-50, 56
- Propagation velocity, sound, 1-3
- Quality of sound, 1-18
- Radiation, loudspeaker, 1-38
  - low- and high-frequency, 1-40
- Radio, 1-1
- Range of audibility, 1-13
- Rarefaction of air, 1-7 – 24
- Ratio, impedance, 1-92
  - turns, 1-90
- Rayleigh disk, 1-106
- Receiver, radio, 1-1
  - telephone, 1-58
- Recording, 1-1
- Reeds, sound of, 1-21, 103
- Re-entrant horn, 1-78
- Reflection of sound, 1-27
- Reflex enclosure, 1-70
- Reinforcement by reverberation, 1-36
- Reproduction, audio, 1-1
- Resonance, 1-103
- Response curve, human ear, 1-110
  - loudspeaker, 1-108
  - microphone, 1-108
- Reverberation, 1-41
  - reinforcement by, 1-36
  - time, 1-31
- Ribbon microphone, 1-50, 56, 60
- Ripple tank, 1-28
- Secondary standard, 1-107
- Sensitivity, microphone, 1-58
- Series-fed networks, 1-94, 98
- Shadow effects, 1-40
- Shock wave, 1-2
- Slit, acoustic, 1-80
- Sonar, 1-1
- Soundboard of piano, 1-7
- Sound, build-up of, 1-31
  - decay of, 1-31
  - direction of, 1-38
  - effect of wind on, 1-35
  - field, 1-105
  - in various materials, 1-6
  - of bars, 1-21
  - of bells, 1-21
  - of musical instruments, 1-7, 19, 21, 23, 38, 103
  - pressure, 1-23, 58, 70
  - quality, 1-18
  - reflection of, 1-28
  - speech, 1-42
  - speed of, 1-3
  - waves, 1-3
- Speaking tube, 1-72
- Speech sounds, 1-42
- Speed of sound, 1-3
- Spider, centering, 1-49

# INDEX

Standard, absolute, 1-105
  secondary, 1-107
Standing waves, 1-24, 28 105
Steel, sound in, 1-6
Supersonic flight, 1-2
Super tweeter, 1-93
Suspension, 1-49

Telephone, 1-55, 58, 104
Temperature, effect of, 2-5
Three-element crossover, 1-101
Timbre, 1-18, 103
Time, reverberation, 1-31
Tone, continuous, 1-30
  interval, 1-9
Tractrix horn, 1-79
Transducer, 1-47
Transformer, matching, 1-60, 89
Transients, 1-41
Transmitter, radio, 1-1
  telephone, 1-55, 58, 104
Triangle, sound of, 1-21
Trumpet, ear, 1-44
  sound of, 1-38
Turns ratio, 1-90
Tweeters, 1-67, 93
Two-element crossover, 1-99

Unidirectional microphone, 1-57

Velocity microphone, 1-50
Velocity particle, 1-3, 23, 58, 70
  propagation, 1-3
Vibration, amplitude of, 1-19
  measurement, 1-1
  periodic 1-7
Violin, sound of, 1-7
Voice coil, 1-49, 65, 69
Volume control, 1-17

Water, sound in, 1-6
Wave expansion, 1-32, 74
Wavelength and frequency, 1-39, 66
Waves, sound, 1-3
  standing, 1-3
Wind instruments, sound of, 1-7
Xylophone, sound of, 1-103